



CRBH 130



Major components		
PART NO.	DESCRIPTION	QTY
250001	Hex bolt M8*30	1
250002	Spring washer Φ8	1
250003	Bigger flat washer Φ8	1
250004	Clutch assembly	1
250005	Belt	1
250006	Engine	1
250007	Locknut M12	4
250008	Spring washer Φ12	4
250009	Ecc, washer Φ12	4
250010	Protective frame	1
250011	Throttle lever assy	1
250011-1	Throttle lever	1
250011-2	Throttle cable	1
250012	Grip	1
250013	Handle	1
250014	Shock absorber for handle	2
250015	Hex bolt M8*20	4
250016	Nylon liner	2
250017	Lining tube	2
250018	Bigger flat washer Φ12	2
250019	Hexagonal bolt M12*65	2
250020	Vibrator control Assembly	1
250021	Vibrator control lever	1
250022	Vibrator control cable	1
250023	Vibrating plate	1
250024	Vibrator assembly	1
250025	Hex bolt M10*45	4
250026	Bigger flat washer Φ10	4
250027	Plate for engine mounting	1
250028	Belt cover(upper)	1
250029	Flat washer Φ8	2
250030	Spring washer Φ8	2
250031	Socket head bolt M8*20	2
250032	Rubber bumper	1
250033	Shock absorber for base plate	4
250034	Flat washer Φ12	4
250035	Nut M12	4
250040	Lock, handle	1
250041	Locknut M10	4
250042	Wheel Assy.	1
250043	Rubber mat	1
250044	Fixing bar	2
250045	Hexagonal bolt M8*30	5
250046	Washer Φ8	5
250047	Nut M8	5



Vibrator Assy		
PARTS NO	DESCRIPTION	QTY
250024-01	Vibrating case	1
250024-32	Vibrating cover	
250024-02	Ecc.rotary shaft, driven	1
250024-03	Ecc. Rotary shaft, drive	1
250024-04	Ball bearing NJ. 206E	4
250024-05	Flat key 10*20	1
250024-06	Flat key 12*20	1
250024-07	Flat key 12*50	1
250024-08	Circlip Φ42	5
250024-09	Eccentric rotator, drive shaft	1
250024-10	Gear	1
250024-11	Dial plate(R/L)	2
250024-12	Bearing 16008	2
250024-13	Knock pin	1
250024-14	Gear rim	1
250024-15	Eccentric rotator, driven	1
250024-16	Stopper	1
250024-17	Screw M20	1
250024-18	Spring	1
250024-19	Hexagonal bolt M10x65	1
250024-20	Nut M10-C	1
250024-21	Oil plug bolt M14*1.5	1
250024-22	Aluminum washer	1
250024-23	Bearing cover / shut-off, driven	1
250024-24	Bearing cover	1
250024-25	Oil seal 28×50×10	1
250024-26	Circlip Φ40	2
250024-27	Flat washer Φ8	12
250024-28	Hexagonal bolt M8*40	4
250024-29	Locknut M8-C	4
250024-30	Socket head bolt M8*20	11
250024-31	Spring washer Φ 8	33

250024-33	Hex bolt M8*20	14
250024-34	Bearing cover/shut-off & Shim/bearing cover	1
250024-35	Bearing cover / shut-off	1
250024-36	Cylinder	1
250024-37	Shim, cylinder	1
250024-38	Position rod	1
250024-39	Rotary sleeve	1
250024-40	Rotator	1
250024-41	Plane bearing	2
250024-42	O-ring 23.6×3.55	1
250024-43	Oil seal 20×30×6	1
250024-44	Clamp spring Φ30	1
250024-45	Plain cushion Φ5*32*2.5	1
250024-46	Spring washer Φ5	1
250024-47	Socket head bolt M5x20-C	1
250024-48	Shim, bearing cover of cylinder	1
250024-49	Bearing cover / shut-off, cylinder	1
250024-50	Mounting plate	1
250024-51	Socket head bolt M8x35	4
250024-52	Spring washer Φ6	3
250024-53	Socket head bolt M6x12	3
250024-54	Flat washer Φ10	2
250024-55	Spring washer Φ10	2
250024-56	Hexagonal bolt M10*30	2
250024-57	Connecting sheet	1
250024-58	Washer, Bearing cover/driven	1
250024-59	Flat key 8x20	1
P250024-60	Belt cover (below)	1
250024-61	Driven pulley wheel(below)	1
250024-62	Concave washer Φ8	1
250024-63	Socket head bolt M8x16	4