



CRBH 170



Major components		
PART NO.	DESCRIPTION	QTY
300001	Hex bolt M8*30	1
300002	Spring washer Φ8	1
300003	Bigger flat Washer Φ8	1
300004.	Clutch assembly	1
300005.	Belt	1
300006.	Engine	1
300007.	Nut M10	4
300008.	Spring washer Φ10	4
300009.	Flat washer Φ10	4
300010.	Protective frame	1
300011.	Throttle lever Assy	1
	Throttle lever	1
	Throttle cable	1
300012.	Grip	1
300013.	Handle	1
300014.	Shock absorber for handle	2
300015.	Hex bolt M8*20	4
300016.	Nylon liner	2
300017.	Lining tube	2
300018	Bigger flat washer Φ12	2
300019	Hex bolt M12*55	2
300020.	Vibrator control Assembly	1
	Vibrator control lever	1
	Vibrator control cable	1
300021	Nut M16	2
300022	Flat washer Φ16	2
300023.	Base plate (without extension plate)	1
300023-1	Base plate (with extension plate)	1
300024.	Vibrator assembly	1
300025.	Hex bolt M16*60	4
300026.	Bigger flat washer Φ10	4
300027.	Plate for engine mounting	1
300028.	Belt cover(upper)	1
300029.	Flat washer Φ8	2
300030.	Spring washer Φ8	2
300031.	Socket head bolt M8*16	2
300032	Rubber bumper	1
300033	Shock absorber for base plate	4
300034	Spring washer Φ12	4
300035	Nut M12	4
300036	Extension plate	2
300037	Flat washer Φ16	6
300038	Spring washer Φ16	6
300039	Hexagonal bolt M16*45	6
300040	Lock, handle	1



Vibrator Assembly

Vibrator Assy		
PART NO.	DESCRIPTION	QTY
300024-1	Belt cover (blow)	1
300024-2	Flat screw M8*20	1
300024-3	Washer, lock Φ8	1
300024-4	Wave washer Φ8	1
300024-5	Driven pulley	1
300024-6	Bearing cover for pulley	1
300024-7	Shim	3
300024-8	Oil seal 28*50*10	1
300024-9	Cover of vibrator	1
300024-37	Vibrating case	1
300024-10	Locating pin Φ8	2
300024-11	Shim	1
300024-12	Bearing NJ206	4
300024-13	Circlip Φ42	5
300024-14	Socket head bolt M8*20	9
300024-15	Spring washer Φ8	9
300024-16	Bearing cover / shut-off	1
300024-17	Socket head bolt M10*65	1
300024-18	Spring	1
300024-19	Nut M10	2
300024-20	Spring clamp	1
300024-21	Screw M20, spring clamp	1
300024-22	Eccentric rotator, drive	1
300024-23	Flat key 8*20	1
300024-24	Ecc. Rotary shaft, drive	1
300024-25	Flat key 12*50	1
300024-26	Flat key 12*20	1
300024-27	Gear , drive	1
300024-28	Eccentric rotator, driven	1
300024-29	Ecc.rotary shaft, driven	1
300024-30	Dial plate(R/L)	2
300024-31	Gear, driven	1
300024-32	Cylinder	1
300024-33	Shim	1
300024-34	Cover, cylinder	1
300024-35	Spring washer Φ6	3
300024-36	Socket head bolt M6*20	3

300024-38	Knock pin	1
300024-39	Position rod	1
300024-40	Rotary sleeve	1
300024-41	Bigger washer $\Phi 5 \times 32 \times 2.5$	1
300024-42	Spring Washer $\Phi 5$	1
300024-43	Socket head bolt M5*16	1
300024-44	Rotator	1
300024-45	Lever, rotator	1
300024-46	Oil seal 20*30*6	1
300024-47	Holder	1
300024-48	Spring washer $\Phi 10$	2
300024-49	Socket head bolt M10*25	2
300024-50	Socket head bolt M8*25	4
300024-51	Bearing 16008	2
300024-52	Oil plug M14*1.5	2
300024-53	O-ring	1
300024-54.55.56	Plane bearing	2
300024-57	Circlip $\Phi 40$	2
300024-58	Clmap spring $\Phi 30$	1
300024-59	Shim, cylinder	1
300024-60	Washer $\Phi 10$	9
300024-61	Socket head bolt M10*30	9
	Battery bracket	
	Centrifugal weight	3
	36AH battary	
	Red ball of throttle lever	