



MF52-3 Explosive view ENGINE



Pos.	Part number	Description
2	520SP0001	Sider Cover
3	520SP0002	Screw M8
5	520SP0003	Clutch
8	520SP0004	Rotor
11	520SP0005	Coil Assy
12	520SP0006	Bolt M5*35
13	520SP0007	Oil Seal
14	520SP0008	Pin
15	520SP0009	Left Crankcase
16	520SP0010	Key
17	520SP0011	Crankshaft
18	520SP0012	Bearing
19	520SP0013	Gasket,crankcase
20	520SP0014	Right Crankcase
21	520SP0015	Oil Seal
22	520SP0016	Pulley
23	520SP0017	Nut M8
24	520SP0018	Alum Washer
25	520SP0019	Recoil Assy
26	520SP0020	Rubber, Branket Tank
29	520SP0021	Cover
31	520SP0022	Cover,cylinder

35	520SP0023	Spark Plug
36	520SP0024-25	Cylinder
37		Gasket,cyliner
38	520SP0026-30	Piston Ring
39		Piston
40		Bearing K10*13*16
41		Piston Pin
42		Snap Ring
43	520SP0031	Cover, Muffler
46	520SP0032	Muffler
47	520SP0033	Gasket, Muffler
48	520SP0034	Gasket, Insulator
49	520SP0035	Insulator
50	520SP0036	Gasket, Carburetor
51	520SP0037	Carburetor
52	520SP0038-43	Body Assy
53		Element
54		Plate
56		Cover
57		Cover, Air Filter
59	520SP0044	Fuel Tank
60	520SP0045	Branket Tank



PART NO.	DESCRIPTION
GD520-2SP0001	CUTIE TRANSMISIE ECHIPATA
GD520-2SP0002	MANETA + CABLU ACCELERATIE