





NO.	Code	DESCRIPTION	QTY
1	91221	BOLT BS1768 3/8-24UNF*38	1
2	94042	FLAT WASHER	1
3	602001	BLADE WASHER	1
4	602005	BLADE	1
5	602057	BLADE ADAPTER	1
6	606028	FRONT WHEEL	2
7	606247	FRONT AXLE	1
8	601006-136	DECK	1
9	90060	NUT M6	8
10	606150	AXLE PLATE	4
11	91404	BOLT M6*14	12
12	91346	BOLT M8X25	3
13	94040	SPRING WASHER	3
14	94041	WASHER	4
15	220013010033	ENGINE	1
16	90063	NUT M5	4
17	90059	NUT M8	4
18	91868	BOLT M8*45	4
19	605006	STEM	4
20	94036	CIRCLIP Ø5	2
21	604098	TORSIONAL SPRING (L)	1
22	604017	AXLE(REAR COVER)	1
23	604095	REAR COVER	1
24	604099	TORSIONAL SPRING (R)	1
25	91881	BOLT M8*16	4
26	601076	RIGHT HANDLE SUPPORT	1
27	605098-206	TRIANGLE KNOB	4
28	605016-206	LOWER HANDLE	1

29	605221	CLIP	1
30	605010-136	BRAKE LEVEL	1
31	605007-053	SOFT GRIP	1
32	90061	NUT M6	2
33	605296	BRAKE CABLE	1
34	92118	CROSS SLOTTED HEAD SCREW M5X25	2
35	605008-206	UPPER HANDLE	1
36	605009	ROPE GUIDE SUPPORT	1
37	90016	NUT M6	1
38	92103	CROSS SLOTTED HEAD SCREW M5X30	2
39	601172	RIGHT HANDLE SUPPORT	1
40	604146	LOWER COVER ASSEMBLY	1
41	604097-069	A STRAW BAG UNDER A STRAW BOX	1
42	606007-206	WHEEL COVER	2
43	90057	NUT M10*1.5	4
44	91867	BOLT	2
45	603003-206	HEIGHT ADJUSTER COVER	1
46	603037	HEIGHT ADJUSTER LEVER	1
47	603002	SPRING LAMINATION(HEIGHT ADJUSTER)	1
48	606001-206	WHEEL COVER	2
49	606241	REAR AXLE	1
50	90058	NUT M6	6
51	603075	HEIGHT ADJUSTMENT LINK BAR	1
52	603062	HEIGHT ADJUSTER SPING	1
53	606002	FRONT WHEEL	2
54	94046	FLAT WASHER	4
55	94057	WASHER $\Phi 8.4 \times 20 \times 2$	2
56	604096	GRASS BOX BRACKET	1



NO.	Code	DESCRIPTION	QTY
1	410208	THE CRANKSHAFT BOX BODY	1
2	415601-138	OIL GAUGE ASSEMBLY	1
3	316101	THE VALVE LIFTER	2
4	292101	ROCKER ARM	2
5	91818	ROCKER ARM FASTENING BOLT ASSEMBLY	2
6	316001	VALVE SPRINGS	2
7	311802	INLET VALVE SPRING SEAT	2
8	300605	CIRCULAR PLATE	1
9	241806	VALVE OIL SEAL	2
10	91816	OIL DRAIN BOLT M10X1.25X15	1
11	91067	STUD M6X77	2
12	91035	STUD M6X100	2
13	94007	OIL DRAIN BOLT WASHER	1
14	93522	THE CRANKSHAFT OIL SEAL	1
15	94225	THE CRANKSHAFT FLAT MAT	1
16	410901	POSITIONING PIN OF CRANKCASE	2
17	97114	THE SPARK PLUG	1
18	413902	CHECK BACK CLIP	1
19	91370	BOLT M6X16	8
20	91366	BOLT M6X18	2
21	91369	BOLT M6X25	8
22	90014	NUT M12X1. 25	1
23	90038	NUT M6	2
24	90035	NUT M6	7
25	310606	BREATHING VALVE SPRING	1
26	93537	PENDULUM STEM SEAL	1
27	96130	AIR FILTER GASKET	1
28	93541	THE CRANKSHAFT OIL SEAL	1
29	414301	CENTRIFUGAL GOVERNOR GEAR ASSEMBLY	1
30	411101	CYLINDER CRANIUM	1
31	95662	EXHAUST PIPE	1
32	410101	CRANKCASE COVER	1
33	411201	THE PISTON	1
34	415501	THE PISTON PIN	1
35	411301	PISTON PIN RETAINER	2
36	411601	PISTON RING ASSEMBLY	1
37	411502	CONNECTING ROD COMPONENT	1
38	419902	CRANKSHAFT TIMING DRIVING GEAR	1
39	410301	THE CRANKSHAFT	1

40	410601	BACK TO THE OIL CHAMBER	1
41	412001	CAMSHAFT ASSEMBLY	1
42	411901	THE VALVE PUSH ROD	2
43	412201	LIMIT PLATE ASSEMBLY	1
44	411701	INLET VALVE	1
45	415901	THE EXHAUST VALVE	1
46	412901	AIR FILTER ELEMENT	1
47	412801	CARBURETOR ASSEMBLY	1
48	96227	INTAKE GASKET	1
49	412301	CARBURETOR CONNECTION BLOCK	1
50	419901	ADD PUMP	1
51	96228	CARBURETOR GASKET	1
52	413701	MUFFLER	1
53	412502	MUFFLER HOUSING	1
54	414801	START THE TRAY ASSEMBLY	1
55	414902	IN THE HOOD	1
56	414101	SPEED REGULATING SPRING B	1
57	414201	VERNIER C SPRING	1
58	412701	THE THROTTLE LEVER	1
59	413901	SWINGING ROD	1
60	414401	SPEED CONTROL CONTROLLER	1
61	414001	CONTROL ARM	1
62	413101	THE FUEL TANK	1
63	293601-055	THE CAP	1
64	97588	IGNITER	1
65	410403	THE FLYWHEEL COMPONENTS	1
66	415301	THE BRAKE COMPONENTS	1
67	96229	OIL RETURN CHAMBER COVER GASKET	1
68	91031	IGNITION STUD	1
69	91070	START COVER STUD	2
70	91061	TANK STUD	2
71	95584	FUEL PIPE	1
72	96230	EXHAUST GASKET	1
73	94408	FUEL PIPE CLAMP	2
74	299904	FILTER	1
75	304501	START THE CUP	1
76	414601	THE IMPELLER	1
77	416306	START SMALL CAP	1
78	96251	CYLINDER HEAD COVER GASKET	1