






CODE	DESCRIPTION	TYPE	QTY
P90-1	Water Tank		1
P90-2	External hexagon bolt	M12*80	2
P90-3	Enlarged Flat Gasket	Ø12	2
P90-4	Handle gluesheath	25*43	2
P90-5	Locked Nut	M10	6
P90-6	Flat Gasket	Ø10	6
P90-7	External hexagon bolt	M10*30	6
P90-8	Plum Blossom Nut	M10	2
P90-9	Upper handle		1
P90-10	Knob Handle		1
P90-11	Nut	M20	1
P90-12	Locked Nut	M10	2
P90-13	Flange Bolt	M10*35	2
P90-14	Lower handle		1
P90-15	Wheel		2
P90-16	Wheel Frame		1
P90-17	Protective Frame		1
P90-18	Flat Cross Bolt	M8*25	2
P90-19	Handle Damper	35*15	2
P90-20	Locked Nut	M8	2
P90-21	External hexagon bolt	M8*40	3
P90-22	Spring Gasket	Ø8	3
P90-23	Flat Gasket	Ø8	6
P90-24	Nut	M8	3
P90-25	Clutch Assembly		1
P90-26	Conical Gasket	Ø8*30	1
P90-27	External hexagon bolt	M8*30	1
P90-28	Spring Gasket	Ø8	1
P90-29	Enlarged Flat Gasket	Ø8*30	1
P90-30	Belt Cover		1
P90-31	Belt	B-838	1

P90-32	Dust-prevent plate		1
P90-33	Spring Gasket	Ø8	1
P90-34	External hexagon bolt	M8*20	1
P90-35	External hexagon bolt	M10*25	4
P90-36	Spring Gasket	Ø10	4
P90-37	Enlarged Flat Gasket	Ø10*35	4
P90-38	Shock absorber		4
P90-39	Flat Gasket	Ø10	4
P90-40	Spring Gasket	Ø10	4
P90-41	Nut	M10	4
P90-42	Bottom Plate		1
P90-43	Water-Leaking Hose		1
P90-44	Flange Bolt	M8*35	2
P90-45	Flexible Hose		1
P90-46	Engine Support Plate		1
P90-47	External hexagon bolt	M8*40	2
P90-48	Exciter		1
P90-49	Flat Gasket	Ø16	4
P90-50	Spring Gasket	Ø16	4
P90-51	Inner Hexagon bolt	M16*40	4
P90-52	Clamp Plate		2
P90-53	Flat Gasket	Ø8	4
P90-54	Locked Nut	M8	4
P90-56	Key	5*40	1
P90-57	External hexagon bolt	M8*20	1
P90-58	Flat Gasket	Ø8	1
P90-59	Locked Nut	M8	1
P90-60	Flange Nut	M8	2
P90-61	Cock		1
P90-62	Clamp		2



CODE	DESCRIPTION	TYPE	QTY
P90-1-1	Inner Hexagon bolt	M10*25	1
P90-2-1	Spring Gasket	10	1
P90-3-1	Enlarged Flat Gasket	Ø10*38	1
P90-4-1	Pulley		1
P90-5-1	Eccentric Shaft		1
P90-6-1	Key	8*20	1
P90-7-1	Inner Hexagon bolt	M8*20	4
P90-8-1	Oil Seal	35*48*10	1
P90-9-1	Spring Gasket	8	4
P90-10-1	Case Cover(Pulley)		1
P90-11-1	“O”Ring	100*3.1	1
P90-12-1	Bearing	6211	1
P90-13-1	Vibrating Case		1
P90-14-1	Copper Gasket	12	1
P90-15-1	Oil Drainage Bolt	M12	1
P90-16-1	Bearing	6211	1
P90-17-1	“O”Ring	100*3.1	1
P90-18-1	Case Cover(shut-off)		1
P90-19-1	Spring Gasket	8	4
P90-20-1	Inner Hexagon bolt	M8*20	4