


This diagram is an exploded view of a motorized machine, likely a small tractor or tillage implement. It shows the following components and their assembly relationships:

- Engine and Drive Components:** A 4-stroke engine (30) is connected to a drive shaft (29) and a clutch assembly (23, 26, 28). The drive shaft is connected to a series of gears (35X(2), 36, 37, 38) and a final drive gear (39).
- Chassis and Frame:** The main frame (54) supports the engine and the chassis (53). The chassis includes a rear axle (43) and a front axle (45).
- Wheels and Tires:** The machine has four wheels (15, 16, 17, 18) with tires (19X(2), 20X(2), 21, 22, 23X(2)). The wheels are mounted on axles (13, 14, 15, 16, 17, 18) and secured with nuts (12, 13, 14, 15, 16, 17, 18).
- Drive Shafts and Gears:** The drive shaft (29) is connected to a series of gears (35X(2), 36, 37, 38) and a final drive gear (39). The drive shaft is also connected to a series of gears (35X(2), 36, 37, 38) and a final drive gear (39).
- Other Components:** The machine includes a fuel tank (54), a battery (53), a control lever (43), a throttle cable (44), a clutch cable (45), a clutch pedal (46), a clutch lever (47), a clutch release bearing (48), a clutch release fork (49), a clutch release bearing (50), a clutch release fork (51), a clutch release bearing (52), a clutch release fork (53), a clutch release bearing (54), a clutch release fork (55), a clutch release bearing (56), a clutch release fork (57), a clutch release bearing (58), a clutch release fork (59), a clutch release bearing (60), a clutch release fork (61), a clutch release bearing (62), a clutch release fork (63), a clutch release bearing (64), a clutch release fork (65), a clutch release bearing (66), a clutch release fork (67), a clutch release bearing (68), a clutch release fork (69), a clutch release bearing (70), a clutch release fork (71), a clutch release bearing (72), a clutch release fork (73), a clutch release bearing (74), a clutch release fork (75), a clutch release bearing (76), a clutch release fork (77), a clutch release bearing (78), a clutch release fork (79), a clutch release bearing (80), a clutch release fork (81), a clutch release bearing (82), a clutch release fork (83), a clutch release bearing (84), a clutch release fork (85), a clutch release bearing (86), a clutch release fork (87), a clutch release bearing (88), a clutch release fork (89), a clutch release bearing (90), a clutch release fork (91), a clutch release bearing (92), a clutch release fork (93), a clutch release bearing (94), a clutch release fork (95), a clutch release bearing (96), a clutch release fork (97), a clutch release bearing (98), a clutch release fork (99), a clutch release bearing (100).

NO.	Code	DESCRIPTION	QTY
1	632008	COMB ASSEMBLY	1
2	632001	THE BLADE ASSEMBLY	1
3	632007	MOUNTING PEDESTAL FOR SHAFT COVER	2
4	93037	BEARING	2
5	632006	BEARING MOUNTING BLOCK	1
6	91325	BOLT M6 * 12	8
7	636006	FROM THE PULLEY	1
8	296503	THE CRANKSHAFT FLAT KEY	1
9	91329	BOLT M6 * 16	5
10	90061	NUT M6	1
11	90059	NUT M8	13
12	91927	SET THE STEP BOLT HIGH	1
13	90057	NUT M10 * 1.5	6
14	94270	FLAT MAT PHI PHI 30 * 10.5 * 2.5	4
15	606140	PUSH WHEEL	4
16	606060	WHEEL SHAFT BOLT M10	2
17	606144-206	WHEEL COVER	4
18	91322	BOLT THE M5 * 12	4
19	636004	FRONT AXLE BUSH	4
20	90015	NUT M5	4
21	636001	FRONT AXLE	1
22	636007	THE BELT	1
23	94041	GASKET 8.4 * 24 * 2	9
24	636008	THE BELT COVER	1
25	90075	NUT M10 * 1.5	1
26	636005	DRIVING WHEEL	1
27	90058	NUT M6	2
28	91345	BOLT M8 * 20	1
29	636009	BELT GUARD	1
30	240021210013	ENGINE DH212	1
31	631005	HOOD	1
32	94261	GASKET 8.4 * 16 * 1	1
33	631002	POWER MOUNTING PLATE	1

34	94057	WASHER Φ 20 * 8.4 * 2	1
35	94040	SPRING WASHER 8.1X2.1	4
36	91349	BOLT M8 * 40	4
37	92113	BOLT M10 * 130	1
38	636002	THE WHEEL AND AXLE BOLT	2
39	636003	SHAFT CUSHION COVERS	2
40	91881	BOLT M8 * 16	4
41	631003	LEFT ARM REST	1
42	631001-136	THE COMB GRASS PLATE	1
43	94036	OPEN RING Φ 5	2
44	634001	HOUGAIBAN	1
45	634002	TORSION SPRING FOR REAR COVER PLATE	2
46	634003	HOUGAIBAN SHAFT	1
47	631004	RIGHT ARM REST BRACKET ASSEMBLY	1
48	633001	HEIGHT CONTROL HANDLE	1
49	633003	RAISE THE CONNECTING ROD	1
50	632005	BEARING COVER	1
51	91926	CONNECTING ROD STEP BOLT	1
52	633002	TOP LEVEL ALIGNING BOARD	1
53	634005	STRAW BAG HOLDER	1
54	634004-069	CLIPPINGS BAG	1
55	635001-206	THE PUSH ROD	1
56	605159	WIRE CLIP	1
57	605098-206	TRIANGLE KNOB	2
58	605008-206	THE PUSH ROD	1
59	635003	SHUT DOWN ARROWS	1
60	91870	SHAPED BOLT M6*33	1
61	605010-136	FLAMEOUT LEVER	1
62	90016	NUT M6	1
63	605007-053	THE PUSH ROD BUSHING	1
64	91868	SHAPED BOLT M8*45	2
65	92107	BOLT M8 * 30	4



NO.	Code		QTY
1	240211	CRANKCASE	1
2	93009	BALL BEARING	2
3	93507	OIL SEAL	2
4	244302	GOVERNOR ASSEMBLY	1
5	243901	SHAFT,GOVERNOR ARM	1
6	96804	WASHER,GOVERNOR ARM SHAFT	1
7	243902	PIN,LOCK	1
8	91816	BOLT, DRAIN PLUG	2
9	94007	WASHER,DRAIN PLUG	2
10	243770	MUFFLER	1
11	635004	FLAMEOUT SWITCH	1
12	240901	DOWEL PIN,CASECOVER	2
13	241208	PISTON	1
14	241606	SCRAPER RING SET ,PISTON	1
15	241503	ROD ASSEMBLY., CONNECTING	1
16	245503	PIN, PISTON	1
17	241301	CLIP, PISTON	2
18	240105	COVER ASSEMBLY, CRANKCASE	1
19	241011	CYLINDER HEAD	1
20	241704	VALVE,IN	1
21	245904	VALVE EXHAUST	1
22	241806	RETURNER,INTAKE VALVE	1
23	246001	SPRING,VALVE	2
24	241801	SEAT, VALVE SPRING,IN	1
25	241802	SEAT, VALVE SPRING,EX	1
26	242202	PLATE,PUSH ROD GUIDE	1
27	242101	ROCKER ASSY	2
28	241804	ROTATOR	1
29	91006	BOLT, STUD	2
30	91007	BOLT, STUD	2
31	242815	CARBURETOR ASSEMBLY	1
32	95404	FUEL LINE 4*8*134+25	1
33	94403	CLIP,FUEL LINE Φ 7.5	1
34	244001	GOVERNOR ARM	1
35	635002	SWITCH OFF BRACKET	1
36	90016	NUT M6	2
37	240391	CRANKSHAFT ASSEMBLY	1
38	246102	LIFTER,VALVE	2
39	96040	PACKING,CASECOVER	1

40	242003	CAMSHAFT ASSEMBLY	1
41	240905	PIN, DOWEL	2
42	91347	BOLT M8X30	6
43	96058	GASKET,CYLINDER HEAD	1
44	91359	BOLT M8*60	4
45	97109	SPARK PULG	1
46	241901	ROD,PUSH	2
47	240501	SHROUD	1
48	91325	BOLT M6X12	12
49	96045	PACKING,HEADCOVER	1
50	241111	COVER COMP,CYLINDER HEAD	1
51	245703	WIND SHIEL COMP.	1
52	91330	BOLT M6X20	1
53	240401	FLYWHEEL ASSEMBLY	1
54	244601	FAN,RECOIL STARTER	1
55	244502	PULLEY,STARTER	1
56	90003	NUT M14*1.5	1
57	97516	IGNITION COIL ASSY	1
58	91331	BOLT M6X25	2
59	96046	PACKING,INTAKE	1
60	242301	INSULATOR,CARBURETOR	1
61	96050	PACKING,CARBURETOR	1
62	94229	SPACER,CARBURETOR	1
63	242701	ROD,GOVERNOR	1
64	244208	SPRING,THROTTLE RETURN	1
65	244740-136A	RECOIL STARTER ASSEMBLY	1
66	244422	SHROUD ASSY,UPPER	1
67	242936	AIR CLEANER ASSEMBLY	1
68	95603	TUBE,BREATHER	1
69	243604	THE CAP	1
70	244101	SPRING,GOVERNOR	1
71	94206	SPRING WASHERS PHI 8	2
72	245601-138	DIPSTICK	1
73	91818	ADJUSTER ROCKER ARM	2
74	90011	NUT M8	2
75	241401-138	THE OIL PLUG	1
76	96054	EXHAUST GASKET	1
77	243130-010	THE FUEL TANK	1