



## 10. PARTS

### FRAMEWORK



| Item No. | Part No.     | Description                  | Qty. |
|----------|--------------|------------------------------|------|
| 1        | 836G815      | SEAT PLATE                   | 1    |
| 2        | B8360805     | PIN                          | 1    |
| 3        | 836G825      | CUP HOLDER                   | 1    |
| 4        | 836G800      | UPPER FRAME                  | 1    |
| 5        | 836G820      | HEAT SHIELD                  | 1    |
| 6        | 1046H8301    | SEAT FASTENER                | 1    |
| 7        | 1046H8304    | SPRING                       | 1    |
| 8        | 1046H8302    | PIN                          | 1    |
| 9        | 836G819      | FRONT PANEL                  | 1    |
| 10       | 836G829      | BOLT                         | 1    |
| 11       | 9909         | HOUR METER                   | 1    |
| 12       | JG846A080011 | CHOKE CABLE                  | 1    |
| 13       | JG846A080012 | CHOKE BUSHING                | 1    |
| 14       | 9907         | CHOKE KNOB                   | 1    |
| 15       | 9346         | FRONT PANEL ACCESS MECHANISM | 2    |
| 16       | 9678         | Handle                       | 1    |
| 17       | 9641         | LIGHT SWITCH                 | 2    |
| 18       | 9018         | BOLT                         | 8    |
|          | 9091         | NUT                          | 8    |
|          | 9922         | WASHER                       | 8    |
|          | 9046         | SPRING WASHER                | 8    |
| 19       | 9059         | NUT                          | 2    |
| 20       | 8360453      | SEAT                         | 1    |
| 21       | 9213A        | BOLT                         | 4    |
|          | 9037         | SPRING WASHER                | 4    |
|          | 9038         | WASHER                       | 4    |
|          | 9032         | NUT                          | 4    |


## GUARD RING



Nijverheidsstraat 10, 1840 Londerzeel/Belgium  
 Tel: +32 (0)52 315 350 - Tel: +32 (0)52 315 351 - Fax: +32 (0)52 315 359  
 E-mail: [info@betontrowel.com](mailto:info@betontrowel.com) - [www.betontrowel.com](http://www.betontrowel.com)  
 BE 0821.249.312

| Item No. | Part No. | Description            | Qty. |
|----------|----------|------------------------|------|
| 1        | 836G711  | TANK PLATE             | 2    |
| 2        | 8360592a | THROTTLE PEDAL         | 1    |
| 3        | 836G701  | CONNECTING ROD         | 1    |
| 4        | 8360592C | PEDAL CONNECTION PLATE | 1    |
| 5        | 8361428  | SUPPORT                | 1    |
| 6        | 8361426  | SUPPORT                | 1    |
| 7        | 9411     | SPRING                 | 1    |
| 8        | 836G720  | SUPPORT                | 1    |
| 9        | 8361427B | CONNECTING ROD         | 1    |
| 10       | 836G730  | SUPPORT                | 1    |
| 11       | 8361062a | SAFETY SWITCH PEDAL    | 1    |
| 12       | 9970     | LED LIGHT              | 4    |
| 13       | 836G831  | FOOT PLATE             | 1    |
| 14       | 836G832  | FOOT PLATE             | 1    |
| 15       | B8360731 | MOUNTING PLATE         | 1    |
| 16       | 836G100  | GUARD RING             | 1    |
| 17       | 8360464  | BATTERY BOX            | 1    |
| 18       | 836G833  | PLATE                  | 1    |
| 19       | 836G830  | FRONT PANEL            | 1    |
| 20       | 9555     | SAFETY SWITCH          | 1    |
| 21       | 9746     | BOLT                   | 3    |
|          | 9023     | NUT                    | 3    |
| 22       | 9220     | BOLT                   | 2    |
|          | 9023     | NUT                    | 2    |


## POWER SYSTEM



Nijverheidsstraat 10, 1840 Londerzeel/Belgium  
 Tel: +32 (0)52 315 350 - Tel: +32 (0)52 315 351 - Fax: +32 (0)52 315 359  
 E-mail: [info@betontrowel.com](mailto:info@betontrowel.com) - [www.betontrowel.com](http://www.betontrowel.com)  
 BE 0821.249.312

| Item No. | Part No.     | Description    | Qty. |
|----------|--------------|----------------|------|
| 1        | 9155         | PIN            | 1    |
| 2        | 8360060      | WASHER         | 1    |
| 3        | 8361815D     | CLUTCH         | 1    |
| 4        | JG846A030006 | BUSHING        | 1    |
| 5        | 0064         | SPRING WASHER  | 1    |
| 6        | 0529         | BOLT           | 1    |
| 7        | 836G305      | BELT GUARD     | 1    |
| 8        | 9974         | BELT           | 2    |
| 11       | 31000037C    | GX690          | 1    |
| 12       | B8360327     | TENSIONER      | 1    |
| 13       | 9027         | RETAINER       | 1    |
| 14       | 9037         | SPRING WASHER  | 2    |
| 15       | 9038         | WASHER         | 10   |
| 16       | 9036         | BOLT           | 4    |
| 17       | 9605         | BOLT           | 1    |
| 18       | 836G300      | MOUNTING PLATE | 1    |
| 19       | B8360325a    | ADJUST PLATE   | 1    |
| 20       | 9063A        | BEARING        | 2    |
| 21       | 31000026a    | MUFFLER        | 1    |

## STEERING SYSTEM




Nijverheidsstraat 10, 1840 Londerzeel/Belgium  
 Tel: +32 (0)52 315 350 - Tel: +32 (0)52 315 351 - Fax: +32 (0)52 315 359  
 E-mail: [info@betontrowel.com](mailto:info@betontrowel.com) - [www.betontrowel.com](http://www.betontrowel.com)  
 BE 0821.249.312

| Item No. | Part No.  | Description            | Qty. |
|----------|-----------|------------------------|------|
| 1        | 836G420   | BRACKET, RIGHT         | 1    |
| 2        | 836G425   | CROSS SHAFT BASE       | 4    |
| 3        | 9973      | BUSHING                | 6    |
| 4        | 836G405   | CROSS SHAFT            | 1    |
| 5        | B8360433  | SHAFT                  | 1    |
| 6        | 836G407   | HANGING BRACKET, RIGHT | 1    |
| 7        | 836G4000R | GEARBOX, RIGHT         | 1    |
| 8        | B8360331  | FLANGE                 | 2    |
| 9        | B8360330  | COUPLING               | 2    |
| 10       | B8360332  | FLANGE                 | 2    |
| 11       | 9601      | BEARING                | 2    |
| 12       | 836G301   | INTERMEDIATE SHAFT     | 1    |
| 13       | B8360314L | PULLEY                 | 1    |
| 14       | 836G410   | BRACKET, LEFT          | 1    |
| 15       | 836G401   | HANGING BRACKET, LEFT  | 1    |
| 16       | 836G4000L | GEARBOX, LEFT          | 1    |
| 17       | B8365500  | PITCH CONTROL ASSY     | 2    |
| 17A      | B8360470  | PITCH HANDLE           | 2    |
| 17B      | 9157A     | PIN                    | 4    |
| 17C      | 9025      | BEARING                | 2    |
| 17D      | 4465502   | BUSHING                | 2    |
| 17E      | 9033      | SPRING WASHER          | 2    |
| 17F      | 4365504   | SPACER                 | 4    |
| 17G      | 9027      | CIRCLIP                | 2    |
| 17H      | 4365503   | THREADED SHAFT         | 2    |
| 18       | 4465505   | BUSHING                | 2    |
| 19       | 9028      | SCREW                  | 2    |
| 20       | B8360465  | CONNECTOR              | 2    |
| 21       | B8360466  | ROD                    | 2    |
| 22       | B8360467  | CONNECTOR              | 2    |
| 23       | 9093      | BOLT                   | 2    |
|          | 9022      | SPRING WASHER          | 2    |
| 24       | 9607      | KEY                    | 1    |
| 25       | 9608      | KEY                    | 2    |
| 26       | 9603      | BOLT                   | 4    |
|          | 9604      | NUT                    | 4    |



|    |      |               |    |
|----|------|---------------|----|
| 27 | 9018 | BOLT          | 28 |
|    | 9046 | SPRING WASHER | 20 |
|    | 9047 | WASHER        | 8  |
| 28 | 9072 | PLUG          | 1  |


## OPERATING SYSTEM



Nijverheidsstraat 10, 1840 Londerzeel/Belgium  
 Tel: +32 (0)52 315 350 - Tel: +32 (0)52 315 351 - Fax: +32 (0)52 315 359  
 E-mail: [info@betontrowel.com](mailto:info@betontrowel.com) - [www.betontrowel.com](http://www.betontrowel.com)  
 BE 0821.249.312

| Item No. | Part No. | Description          | Qty. |
|----------|----------|----------------------|------|
| 1        | 836G220  | DRIVE LEVER, RIGHT   | 1    |
| 2        | 836G205  | DRIVE LEVER BASE     | 2    |
| 3        | 836G200R | CROSS BUSHING, RIGHT | 1    |
| 4        | 836G226  | SHAFT BASE           | 2    |
| 5        | 836G235  | BUSHING              | 2    |
| 6        | 836G229  | PLATE                | 1    |
| 7        | 836G232  | SHAFT                | 1    |
| 8        | 836G233  | ADJUST SHAFT         | 1    |
| 9        | 836G234  | SHAFT                | 1    |
| 10       | 836G228  | SHAFT                | 1    |
| 11       | 836G227  | BUSHING              | 1    |
| 12       | 836G200L | CROSS BUSHING, LEFT  | 1    |
| 13       | 836G210  | LEVER                | 2    |
| 14       | 836G222  | DRIVE LEVER, LEFT    | 1    |
| 15       | 8361301  | WATER SPRAY BUTTON   | 1    |
| 16       | 9035G2   | GRIP                 | 1    |
| 17       | 9035G1   | GRIP                 | 1    |
| 18       | 9030     | PIN                  | 2    |
| 19       | 9703     | BOLT                 | 8    |
|          | 9259     | NUT                  | 8    |
| 20       | 9944     | BEARING              | 6    |
| 21       | 9168G    | NUT                  | 6    |
| 22       | 9945     | BEARING              | 2    |
| 23       | 9509     | SPRING WASHER        | 2    |
| 24       | 9507A    | BOLT                 | 2    |
|          | 9259     | NUT                  | 8    |
| 25       | 9702A    | BOLT                 | 3    |
|          | 9513     | NUT                  | 2    |
| 27       | 9500     | BEARING              | 1    |
| 28       | 9501     | BEARING              | 5    |
| 29       | 9514     | NUT                  | 4    |
| 30       | 9040A    | BOLT                 | 4    |
|          | 9236     | NUT                  | 4    |
| 31       | 9504     | SPRING WASHER        | 1    |
| 32       | 9972     | BEARING              | 8    |
| 33       | G223     | SPACER               | 4    |
| 34       | 9502b    | NIPPLE               | 2    |
| 35       | 9232     | BOLT                 | 4    |
|          | 9038     | WASHER               | 4    |
|          | 9037     | SPRING WASHER        | 4    |


## GEARBOX ASSEMBLY (LEFT)



| Item No. | Part No.  | Description          | Qty. |
|----------|-----------|----------------------|------|
| 1        | 4364100   | RELEASE VALVE        | 2    |
| 2        | 8364005   | GEARBOX COVER        | 1    |
| 3        | 4464008   | SHIMMING             | 2    |
| 4        | 4364007   | BOLT                 | 1    |
| 5        | 4364006   | PRESSURE WASHER      | 1    |
| 6        | 9144      | BEARING              | 1    |
| 7        | 8364010L  | BRONZE GEAR, LEFT    | 1    |
| 8        | 836G4003L | GEARBOX CASING, LEFT | 1    |
| 9        | B8364013L | COUNTER SHAFT, LEFT  | 1    |
| 10       | 9611      | KEY                  | 1    |
| 11       | 9143      | BEARING              | 1    |
| 12       | 4464015   | SHIMMING             | 4    |
| 13       | 4464012   | BEARING FLANGE       | 1    |
| 14       | 9043      | SCREW                | 12   |
| 15       | 9055      | SEAL                 | 1    |
| 16       | 9053      | SCREW                | 2    |
| 17       | 8364011L  | MAIN SHAFT, LEFT     | 1    |
| 18       | 9154      | KEY                  | 1    |
| 19       | 9222A     | BEARING              | 1    |
| 20       | 9153      | SEAL                 | 1    |
| 21       | 4466002   | PRESSURE PLATE COVER | 1    |
| 22       | 9140      | BEARING              | 1    |
| 23       | 8366003   | PRESSURE PLATE       | 1    |
| 24       | 8366005L  | SPIDER PLATE, LEFT   | 1    |
| 25       | 4466004   | BUSHING              | 1    |
| 26       | 9068      | SCREW                | 1    |
| 27       | 4466006   | LIFT ARM             | 4    |
| 28       | 4366100G  | BLADE                | 4    |
| 29       | 9072      | PLUG                 | 4    |
| 30       | 8366001   | TROWEL ARM           | 4    |
| 31       | 4366007a  | ADJUST BUSHING       | 4    |
| 32       | 9215      | BOLT                 | 4    |
|          | 9037      | SPRING WASHER        | 4    |
|          | 9038      | WASHER               | 4    |
| 33       | 9040      | BOLT                 | 4    |
|          | 9037      | SPRING WASHER        | 4    |
|          | 9038      | WASHER               | 4    |

|    |          |                 |   |
|----|----------|-----------------|---|
| 34 | 9540     | SCREW           | 4 |
|    | 9059     | NUT             | 4 |
| 35 | 9067     | SCREW           | 4 |
|    | 9059     | NUT             | 4 |
| 36 | 9066     | BOLT            | 4 |
|    | 9046     | SPRING WASHER   | 4 |
| 37 | 9156     | KEY             | 1 |
| 38 | B8365510 | YOKE ARM        | 1 |
| 39 | 4465509  | SHAFT, YOKE ARM | 1 |
| 40 | 9202     | CIRCLIP         | 2 |
| 41 | 9064     | SIGHT GLASS     | 1 |
| 42 | 9152     | SEAL            | 2 |
| 43 | 4464014  | BEARING FLANGE  | 1 |
| 44 | 9141     | BEARING         | 1 |
| 45 | 9118     | SCREW           | 8 |
| 46 | 9040     | BOLT            | 1 |
|    | 9236     | NUT             | 1 |
| 47 | 9502     | NIPPLE          | 4 |
| 48 | 8366007L | RETURN SPRING   | 4 |
| 49 | 8366008  | BUSHING         | 4 |
| 50 | 9531     | KEY             | 1 |

## GEARBOX ASSEMBLY (RIGHT)




| Item No. | Part No.  | Description           | Qty. |
|----------|-----------|-----------------------|------|
| 1        | 4364100   | RELEASE VALVE         | 2    |
| 2        | 8364005   | GEARBOX COVER         | 1    |
| 3        | 4464008   | SHIMMING              | 2    |
| 4        | 9145      | BOLT                  | 1    |
| 5        | 4364006   | PRESSURE WASHER       | 1    |
| 6        | 9144      | BEARING               | 1    |
| 7        | 8364010R  | BRONZE GEAR, RIGHT    | 1    |
| 8        | 836G4003R | GEARBOX CASING, RIGHT | 1    |
| 9        | B8364013R | COUNTER SHAFT, RIGHT  | 1    |
| 10       | 9611      | KEY                   | 1    |
| 11       | 9143      | BEARING               | 1    |
| 12       | 4464015   | SHIMMING              | 4    |
| 13       | 4464012   | BEARING FLANGE        | 1    |
| 14       | 9043      | SCREW                 | 12   |
| 15       | 9055      | SEAL                  | 1    |
| 16       | 9053      | SCREW                 | 2    |
| 17       | 8364011R  | MAIN SHAFT, RIGHT     | 1    |
| 18       | 9154      | KEY                   | 1    |
| 19       | 9222A     | BEARING               | 1    |
| 20       | 9153      | SEAL                  | 1    |
| 21       | 4466002   | PRESSURE PLATE COVER  | 1    |
| 22       | 9140      | BEARING               | 1    |
| 23       | 8366003   | PRESSURE PLATE        | 1    |
| 24       | 8366005R  | SPIDER PLATE, RIGHT   | 1    |
| 25       | 4466004   | BUSHING               | 1    |
| 26       | 9068      | SCREW                 | 1    |
| 27       | 8366006   | LIFT ARM              | 4    |
| 28       | 4366100G  | BLADE                 | 4    |
| 29       | 9072      | PLUG                  | 4    |
| 30       | 8366001   | TROWEL ARM            | 4    |
| 31       | 4366007a  | ADJUST BUSHING        | 4    |
| 32       | 9215      | BOLT                  | 4    |
|          | 9037      | SPRING WASHER         | 4    |
|          | 9038      | WASHER                | 4    |
| 33       | 9040      | BOLT                  | 4    |
|          | 9037      | SPRING WASHER         | 4    |
|          | 9038      | WASHER                | 4    |




|    |          |                  |   |
|----|----------|------------------|---|
| 34 | 9540     | SCREW            | 4 |
|    | 9059     | NUT              | 4 |
| 35 | 9067     | SCREW            | 4 |
|    | 9059     | NUT              | 4 |
| 36 | 9066     | BOLT             | 4 |
|    | 9046     | SPRING WASHER    | 4 |
| 37 | 9156     | KEY              | 1 |
| 38 | B8365510 | YOKE ARM         | 1 |
| 39 | 4465509  | SHAFT, YOKE ARM  | 1 |
| 40 | 9202     | CIRCLIP          | 2 |
| 41 | 9064     | SIGHT GLASS      | 1 |
| 42 | 9152     | SEAL             | 2 |
| 43 | 4464014  | BEARING FLANGE   | 1 |
| 44 | 9141     | BEARING          | 1 |
| 45 | 9118     | SCREW            | 8 |
| 46 | 9040     | BOLT             | 1 |
|    | 9236     | NUT              | 1 |
| 47 | 9502     | NIPPLE           | 4 |
| 48 | 8366007R | RETURNING SPRING | 4 |
| 49 | 8366008  | BUSHING          | 4 |
| 50 | 9531     | KEY              | 1 |

## FUEL- & WATER SYSTEM



| Item No. | Part No.   | Description                   | Qty. |
|----------|------------|-------------------------------|------|
| 1        | FT8360710  | TANK HOOP                     | 2    |
| 2        | B8361073PL | WATER/FUEL TANK               | 2    |
| 3        | B8360731   | MOUNTING PLATE                | 1    |
| 4        | 8361071    | JOINT                         | 12   |
| 5        | 10202003   | WATER PIPE                    | 1    |
| 6        | 9516       | BOLT                          | 4    |
|          | 9517       | NUT                           | 4    |
| 7        | 8361142    | SOLENOID PILOT ACTUATED VALVE | 1    |
| 8        | 9230       | BOLT                          | 2    |
|          | 9128       | SPRING WASHER                 | 2    |
|          | 9038       | WASHER                        | 2    |
| 9        | 8361067    | WATER PUMP                    | 1    |
| 10       | 8361476    | VALVE                         | 1    |
| 11       | 9010       | BOLT                          | 1    |
| 12       | 10202004   | FUEL PIPE                     | 1    |
| 13       | 9902       | BOLT                          | 4    |
|          | 9023       | NUT                           | 4    |
| 14       | 8361476A   | JOINT                         | 2    |

## CLUTCH ASSEMBLY



| Item No. | Part No.   | Description   | Qty. |
|----------|------------|---------------|------|
| 3A       | 9472       | CIRCLIP       | 2    |
| 3B       | 8361815D1  | CLUTCH BODY   | 1    |
| 3C       | 8361815C7  | SPRING        | 2    |
| 3D       | 8361815CA3 | SHOES ASSY    | 1    |
| 3E       | 9471       | CIRCLIP       | 1    |
| 3F       | 9470       | BEARING       | 2    |
| 3G       | 8361815C6  | BUSHING       | 1    |
| 3H       | 8361815C2  | SHOES HOLDER  | 1    |
| 3J       | 8361815C5  | COVER         | 1    |
| 3K       | 9220       | BOLT          | 3    |
|          | 9022       | SPRING WASHER | 3    |
|          | 9330       | WASHER        | 3    |