



Explosion View




Ref.No.	Description	Ref.No.	Description
65H-1	foundation	65H-18	In-feed
65H-2	Roller	65H-19	Emergency stop fixation
65H-3	Blade	65H-20	Rubber fixation
65H-4	Wheel axis	65H-21	Emergency stop switch
65H-5	Wheel	65H-22	spring
65H-6	Pulley	65H-23	rubber
65H-7	Belt	65H-24	Switch
65H-8	Belt cover	65H-25	Switch cover
65H-9	Clutch	65H-26	Angle bar
65H-10	Belt inner cover	65H-27	In-Feed extension
65H-11	Bearing	65H-28	handle
65H-12	Bearing fixation plate	65H-29	Switch extension
65H-13	Support foot	65H-30	Flange
65H-14	Discharge chute	65H-31	Lower Blade
65H-15	Chute adjust	65H-32	Foot rubber
65H-16	engine	65H-33	Bearing cover
65H-17	Engine fixation plate	65H-34	Wheel pin

FIG.1 CRANKCASE. / GEAR ASSY, GOVERNOR.




REF NO	PART NO	DESCRIPTION	QTY
E01-1	11310-Z531610-00A0	CRANKCASE SUBASSEMBLY.	1
E01-2	16400-Z010110-00A0	GEAR ASSY, GOVERNOR	1
E01-3	16061-Z010110-00A0	ARM, GOVERNOR	1
E01-4	11007-Z010110-00A0	BOLT, DRAIN PLUG	2
E01-5	90408-Z010110-00A0	FLAT WASHER	2
E01-6	90548-0205-CLA0	DEEP GROOVE BALL BEARING	1
E01-7	90682-Z300110-00A0	SEAL, OIL	1
E01-8	90408-Z010210-00A0	FLAT WASHER	1
E01-9	90501-Z010110-00A0	COTTER PIN	1

FIG.2 COVER SUBASSEMBLY, CRANKCASE




REF NO	PART NO	DESCRIPTION	QTY
E02-1	11411-Z441010-00A0	COVER, CRANKCASE	1
E02-2	90547-Z530110-00A0	DEEP GROOVE BALL BEARING	1
E02-3	90682-Z300110-00A0	SEAL, OIL	1
E02-4	11001-Z440110-00A0	GASKET, CRANKCASE	1
E02-5	90502-0912-00A0	POSITION PIN - TYPE A	2
E02-6	15010-Z010130-Q5A0	DIPSTICK SUBASSEMBLY, OIL	2
E02-8	90001-0832-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	6

FIG.3 HEAD SUBASSEMBLY, CYLINDER / PLUG,SPARK




REF NO	PART NO	DESCRIPTION	QTY
E03-1	12131-Z950110-00A0	GASKET, CYLINDER HEAD	1
E03-2	12410-Z440110-00A9	COVER SUBASSEMBLY, CYLINDER HEAD	1
E03-3	12004-Z440110-00A0	CYLINDER HEAD COVER GASKET	1
E03-4	17004-Z010110-00A0	TUBE, BREATHER	1
E03-5	90001-0612-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	3
E03-6	90204-Z010210-01A0	STUD BOLT	2
E03-7	90203-Z010110-01A0	STUD BOLT	2
E03-8	90502-1114-00A0	POSITION PIN - TYPE A	2
E03-9	12003-Z010110-00A0	CYLINDER HEAD BOLT	4
E03-10	30010-Z010110-00A0	PLUG, SPARK	1
E03-11	12140-Z810210-00A0	HEAD SUBASSEMBLY, CYLINDER	1
E03-12	90001-0616-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	1

FIG.4 ROD,CRANKSHAFT CONNETING




REF NO	PART NO	DESCRIPTION	QTY
E04-1	13300-Z530610-00A1	CRANKSHAFT ASSY.	1

FIG.5 RING SET,OIL / ROD,CRANKSHAFT CONNETING




REF NO	PART NO	DESCRIPTION	QTY
E05-1	13200-Z140210-00A9	RING ASSY, PISTON	1
E05-2	13122-Z010110-00A0	CLIP, PISTON PIN	2
E05-3	13111-Z140220-00A9	PISTON	1
E05-4	13121-Z010110-00A0	PIN, PISTON	1
E05-5	13010-Z440210-00A9	ROD, CONNECTING	1

FIG.6 TRAIN,VALVE / CAMSHAFT SUBASSEMBLY




REF	PART NO	DESCRIPTION	QTY
E06-1	14200-Z530210-00A9	CAMSHAFT ASSY.	1
E06-2	12110-Z810120-00A9	VALVES SET	1
E06-3	12112-Z810210-00A0	SEAT, VALVE SPRING	2
E06-4	12109-Z810110-00A0	CLAMP, VALVE LOCK	4
E06-5	12103-Z030110-00A0	SPRING, VALVE	2
E06-6	12101-Z810210-00A0	GUIDE, SEAL	1
E06-7	14081-Z040110-00A0	TAPPET, VALVE	2
E06-8	14071-Z440110-00A0	LIFTER, VALVE	2
E06-9	14090-Z010110-00A0	PLATE SUBASSEMBLY, LIFTER STOPPER	1
E06-10	14313-Z010110-00A0	ROCKSHAFT BOLT	2
E06-11	14311-Z010110-00A0	ROCKER, VALVE	2
E06-12	14314-Z010110-00A0	NUT, VALVE ADJUSTING	2
E06-13	14312-Z010110-00A0	NUT, VALVE LOCK	2

FIG.7 STARTER,RECOIL




REF NO	PART NO	DESCRIPTION	QTY
E07-11	90001-0608-01	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	3
E07-12	28200-Z300510-H600	STARTER ASSY, RECOIL	1

FIG.8 SHROUD / SHIELD,LOWER




REF NO	PART NO	DESCRIPTION	QTY
E08-1	28110-Z010810-H600	SHROUD	1
E08-2	19304-Z010610-00A0	SHROUD, CYLINDER BODY	1
E08-3	19340-Z010120-00A0	SHIELD,LOWER	1
E08-4	35540-Z060230-Q2A0	SWITCH SUBASSEMBLY, STOP ENGINE	1
E08-5	90001-0610-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	2
E08-6	90001-0616-01A0	BOLT	1
E08-7	90001-0612-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	4

FIG.9 CARBURETOR ASSY.




REF NO	PART NO	DESCRIPTION	QTY
E09-1	16100-Z530810-00A9	CARBURETOR ASSY.	1
E09-2	17001-Z1D0110-00A0	AIR CLEANER SEAL GASKET	1
E09-3	16001-Z010110-00A0	CARBURETOR SEAL GASKET	1
E09-4	16003-Z010110-0001	PLATE, CARBURETOR INSULATOR	1
E09-5	16002-Z010110-00A0	GASKET, CARBURETOR INSULATOR	1

FIG.10 CLEANER, AIR




REF NO	PART NO	DESCRIPTION	QTY
E10-1	17104-Z300510-00A0	AIR CLEANER CASE	1
E10-2	17151-Z010410-00A0	ELEMENT, AIR CLEANER	1
E10-3	17153-Z300510-0000	BRACKET, AIR CLEANER ELEMENT	1
E10-4	17140-Z300510-0000	ELBOW SUBASSEMBLY, AIR CLEANER	1
E10-5	17100-Z301410-00A9	AIR CLEANER	1
E10-6	90305-0600-31A0	HEXAGON NUT WITH FLANGE	2
E10-7	17003-Y110130-00A0	SUPPORT, ATR CLEANER	1
E10-8	90001-0612-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	1

FIG.11 MUFFLER ASSY.




REF NO	PART NO	DESCRIPTION	QTY
E11-1	90303-0800-31A0	TYPE 1 HEXAGON NUT	2
E11-2	18001-Z440110-00A0	GASKET, EXHAUST OUTLET	1
E11-3	18100-Z012010-H6A9	MUFFLER ASSY.	1

FIG.12 TANK ASSY, FUEL




REF NO	PART NO	DESCRIPTION	QTY
E12-1	16620-Z010710-H6A2	FUEL TANK	1
E12-2	16652-Z010710-00A0	STRAINER, FUEL	1
E12-3	16730-Z510210-00A0	COVER, FUEL TANK	1
E12-4	16680-Z010110-00A0	OUTLET SUBASSEMBLY, FUEL TANK OIL	1
E12-5	90740-Z010510-00A0	COLLAR	3
E12-6	90686-Z081310-00A0	TUBE, FUEL	1
E12-7	90001-0630-01A0	BOLT	1
E12-8	90001-0616-01A0	BOLT	2
E12-9	30431-Z010110-00A0	JACKET, RUBBER	1
E12-11	16750-Z010421-00M0	COCK ASSY, FUEL	1
E12-12	90102-0616-A1A0	HEXAGON SOCKET HEAD CAP SCREW	1
E12-13	90686-Z450210-00M0	TUBE, FUEL	1
E12-14	16602-Z010110-00A0	GASKET, FUEL TANK RUBBER	2
E12-15	16612-Z010110-00A0	FRAME, FUEL TANK INSTALLTION	1
E12-16	90310-0600-31A0	NUT	2
E12-17	90740-Z010510-00A0	COLLAR	1

FIG.13 FLYWHEEL / IMPELLER / STARTER PULLEY / IGNITION COIL



REF NO	PART NO	DESCRIPTION	QTY
E13-1	13501-Z010110-00A0	NUT, FLYWHEEL	1
E13-2	28002-Z010310-00A0	PULLEY,STARTER	1
E13-3	19352-Z440110-00A0	IMPELLER	1
E13-4	13510-Z440110-00A0	FLYWHEEL SUBASSEMBLY	1
E13-7	90001-0625-01A0	BOLT	2
E13-9	30400-Z440410-00B0	COIL, IGNITION	1

FIG.14 CONTROL ASSY, THROTTLE



REF NO	PART NO	DESCRIPTION	QTY
E14-1	16520-Z440310-00A0	CONTROL ASSY, THROTTLE	1
E14-2	16063-Z050120-00A0	SPRING, GOVERNOR	1
E14-3	16062-Z010110-00A0	ROD, GOVERNEOR	1
E14-4	16012-Z010110-00A0	SPRING, THROTTLE VALVE RETURNING	1
E14-5	16070-Z010110-00A0	GOVERNOR BRACKET SUBASSEMBLY	1
E14-6	90001-0610-01A0	BOLT	2
E14-7	16072-Z010110-00A0	BOLT, GOVERNOR SUPPORT	1
E14-8	90305-0600-31A0	HEXAGON NUT WITH FLANGE	1